


SISTEMA VISUALTECH

AJUSTE DE BALANCE - BALANCE ADJUST




AJUSTE DE BALANCE - BALANCE ADJUST

Retocar ligeramente (solo si es necesario) para eliminar acoplamiento.

Retouch slightly (only if it is necessary) to remove coupling.

SISTEMA VISUALTECH

AJUSTE DE BALANCE - BALANCE ADJUST



AJUSTE DE BALANCE - BALANCE ADJUST

Retocar ligeramente (solo si es necesario) para eliminar acoplamiento.

Retouch slightly (only if it is necessary) to remove coupling.